103555

BLUE MAX

Premium Pot & Pan Detergent

A concentrated high foaming blend of synthetic detergents for removing the most stubborn food stains, soils and grease spots from dishes, pots and pans. Rinse free. Excellent for hard water.

Removes the heaviest soil, yet is gentle on hands. Heavy viscous formula eliminates wasted product and breaks through grease. Leaves hands soft and smooth. Rinses freely with water leaving no hard water films. Biodegradable.



PRODUCT INFORMATION:

- · Concentrated, high foaming detergent for manual dishwashing
- Breaks through the toughest soils, grease and baked-on food
- · Pleasant, fresh scent eliminates odors

	70.00
pH	7.0 - 9.0
Form	Liquid
Fragrance	Pleasant
Color	.Dark blue
Packaged	4/1 gl Case, 5 gl Pail, 55 gl Drum

DIRECTIONS FOR USE:

FOR DISHES, POTS AND PANS: Pour 1 ounce into 15 gallons of water, wash and rinse. Allow to air dry. For removing grease quickly and easily from pots and pans, use a few drops in the pan.

IMPORTANT SAFETY INFORMATION:



WARNING

Causes skin irritation. Causes serious eye irritation.

Wash hands thoroughly after handling. Wear protective gloves, protective clothing, eye protection and face protection.

FIRST AID: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention. IF ON SKIN: Wash with plenty of water. If skin irritation occurs: Get medical attention. Take off contaminated clothing and wash before reuse.

Emergency Response Number ChemTel Inc. 1-800-255-3924





