

RESTROOM CLEANER

100926

PTC-85

Porcelain and Tile Cleaner



PRODUCT INFORMATION:

- Highly effective mild acid cleaner
- Non-fuming formula, easy to use
- Effectively removes scale, rust, discoloration and stains from restroom surfaces

pH 1.5 - 2.5
Form Liquid
Fragrance Pleasant
Color Opaque light blue
Packaged 12/1 qt Case, 4/1 gl Case

DIRECTIONS FOR USE:

TOILET BOWLS: Remove as much water as possible from bowl. Pour several ounces of cleaner into bowl or saturate mop with cleaner. Mop entire surface thoroughly. Flush to rinse. **URINALS:** Saturate mop with cleaner, swab all surfaces including flush ring, then flush. Remove strainer, swab inside of drain and outlet, let soak for five minutes, flush again. **TOILET TANKS:** Scrub with saturated mop and rinse thoroughly. **FLOORS AROUND BOWLS & URINALS:** For concrete floors, dilute with 4 parts water. For ceramic tile floors, dilute with 2 parts water. Apply diluted cleaner with mop and rinse. Wash with neutral floor cleaner. Do not use on marble or resilient flooring. **PORCELAIN ENAMEL:** For maintenance of porcelain enamel surfaces, dilute with 4 parts water. Apply with swab or brush. Do not allow cleaner to dry on surface. Rinse immediately with clean cold water. **OTHER SURFACES:** To clean painted, lacquered, varnished or plastic surfaces, dilute with 2 parts water, apply with swab or brush, rinse immediately. Cleaner should not remain on surfaces more than 2 minutes. For cleaning of stainless steel coffee urns and sterilizers, dilute with 3 parts water and apply with swab or brush. Rinse.

IMPORTANT: Do not use on chipped or cracked enamel surfaces or porcelain enamel that is not acid resistant. Do not use on metal or plated fixtures that are not guaranteed acid resistant. Test on an inconspicuous spot before using on colored grouting. Product may cause discoloration. Avoid splashing on cotton or synthetic fabrics.

IMPORTANT SAFETY INFORMATION:



WARNING

May be corrosive to metals. Causes skin irritation. Causes serious eye irritation.

Wear protective gloves, protective clothing, eye protection and face protection. Keep only in original container. Wash hands thoroughly after handling. Store in corrosive resistant container with a resistant inner liner.

FIRST AID: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention. **IF ON SKIN:** Wash with plenty of soap and water. If skin irritation occurs: Get medical attention.

Emergency Response Number ChemTel Inc. 1-800-255-3924

SOLUTIONS FOR A CLEANER WORLD™



THEOCHEM LABORATORIES, INC. 7373 Rowlett Park Drive • Tampa, Florida 33610 • (813) 237-6463 • www.theochem.com

MADE IN
USA
100926-0517v1